

Update your Mousetrapper

Follow these steps to update your Mousetrapper:

- 1. Go to MT Keys in your browser: mtkeys.mousetrapper.com
- 2. Click on Software and then on MFU (see image below).

Mousetrapper	> Device Software
Connect with MT Keys Here you can customize your Mousetrapper so that the functions of the buttons suit your workflow. Connect a device to the computer and click the button below. Search devices Help	Indial Dynamic Upsator Metalgoer Finnare Upsator Editory 2.0.1.00/ndees
Software Compatible devices Mousetrapper.com	
© 2024 Mousetrapper® – MT Keys 47.15-35	

- 3. Then go to Downloads in your browser and click on the MFU file.
- 4. Follow the instructions to install.



- 5. After installation, close your browser.
- 6. Then click on the MFU icon which should be on your desktop.





7. With the Mousetrapper connected via cable, follow these steps.



- 8. To make sure you have successfully updated your Mousetrapper, go back to mtkeys.mousetrapper.com.
- 9. With the Mousetrapper connected via cable, click "Search devices".



- 10. Select the device and click connect.
- 11. In the top right corner, there are three dots; click on them and then go to "About".
- 12. There you can see which version you have.

s.mousetrapper.com försöker ansluta till en HID-enhet		About ×
MT Advance2	ර reset	Mousetrapper [®]
	🛛 🖄 Save Lathund	MT Keys version 4.7.19-35
		This device
	🖄 Visit our website	Name Mousetrapper Advance2 (rev 4.2) Version 4.3.47
	🖓 Help	Hardware ID e6614c-311b-4c47-31
O Anslut Avbryt	@ About	Save track data Download (19.KB) 🕹 Copyright © 2024 Trapper Data AB